0 TO 40 MPH

L	$\frac{\text{WT}}{120} \times \text{S}_{SL}^2$	(SYMMETRICAL ABOUT CENTERLINE)
	$\frac{\text{WT}}{60} \times \text{S}_{SL}^2$	(OFFSET)

WT = WIDTH OF TURN LANE

 S_{SL} = POSTED SPEED LIMIT


L = LENGTH OF CHANNELIZATION

NOTES:

1. SEE ENGINEER FOR POCKET LENGTH.

45 MPH OR MORE

L	$\frac{\text{WT}}{2} \times \text{S}_{\text{SL}}^2$	(SYMMETRICAL ABOUT CENTERLINE)
	WT X S _{SL}	(OFFSET)





NONCONTINUOUS LEFT TURN LANE

DRAWING NUMBER	CH-190-1
SCALE	NONE
REVISION DATE	2/22
DEPARTMENT	TRANS